


Loctite®

Part Number 1544934

Description: 30ml Manual Syringe Dispenser

1. Press and hold white release button



2. Insert Plunger in direction shown until the plunger face is seated.
3. Place barrel end over plunger face and twist clockwise so barrel ears slide under face tabs. (This will be a loose fit to accommodate other types of 30ml syringes. The plunger when moved forward will securely seat in the barrel.)



4. Pull the trigger to dispense

Replacement Plungers

Item No. 1544933 is included in this package as it is properly sized to dispense Loctite® 30ml Syringes. Item No. 1544933 is also sold separately, visit www.loctiteequipment.com.

Henkel Corporation
One Henkel Way
Rocky Hill, CT 06067-3910

Henkel Canada Corporation
2225 Meadowpine Boulevard
Mississauga, Ontario L5N 7P2

Henkel Capital, S.A. de C.V.
Calzada de la Viga s/n Fracc. Los Laureles
Loc. Tulpetlac, C.P. 55090
Ecatepac de Morelos, Edo. de México

**Henkel Automotive
Technology Center**
2455 Featherstone Road
Auburn Hills, Michigan 48326

Henkel Ltda.
Rua Karl Huller, 136 – Jd.
Canhema 09941-410
Diadema/SP, Brazil

www.loctite.com

Loctite is a trademark of Henkel Corporation, U.S.A. © Copyright 2008. Henkel Corporation
All rights reserved. Data in this instruction sheet is subject to change without notice.
Instructions P/N: 8902771, Date: 02/2011

